

---

# Manual For A 1850 Coleman Powermate Generator

---

*Manual For A 1850  
Coleman Powermate  
Generator*

*Downloaded from  
[web1.enteraskincare.com](http://web1.enteraskincare.com)  
by Reilly & Wendy*

---

## **INTRODUCTION: WHY THE MANUAL FOR A 1850 COLEMAN POWERMATE GENERATOR STILL MATTERS**

---

In the world of portable power, few names carry the weight of reliability and history quite like Coleman Powermate. The Coleman Powermate 1850, a rugged workhorse from a bygone era, remains in

service for many homeowners, campers, and tradespeople who appreciate its simple, robust design. However, owning a vintage generator comes with a unique challenge: finding and understanding the **manual for a 1850 Coleman Powermate generator**. This document is more than a faded booklet; it is the key to safe operation, routine maintenance, and troubleshooting that can extend the life of your machine for years to come. Whether you have just

acquired a used model or are dusting off a long-forgotten unit, this comprehensive guide will walk you through everything you need to know to locate, interpret, and apply the information contained within that essential manual.

---

## **UNDERSTANDING THE COLEMAN POWERMATE 1850 GENERATOR**

---

The Coleman Powermate 1850 is a portable generator designed to deliver 1850 watts of surge power and typically 1500 to 1650 watts of continuous power. This puts it squarely in the mid-range category for small to medium household and recreational use. It was commonly powered by a dependable Briggs & Stratton engine, known for its simplicity and ease of parts availability. These

generators were built to provide backup power for essential appliances, power tools on job sites, or electricity for camping and tailgating. Understanding the machine's capabilities begins with a careful reading of the **manual for a 1850 Coleman Powermate generator**, which contains the exact specifications for your specific model variant.

# Common Applications for the 1850 Watt

# Generator

With its 1850 watt starting capacity, this generator can handle a surprising number of tasks when used judiciously. Typical applications include:

- Powering lights, a refrigerator, and a sump pump during an outage.
- Running small power tools such as drills, circular saws, and air compressors.
- Supplying electricity for recreational vehicles (RVs) and campers.
- Providing backup for essential medical equipment like a CPAP machine.
- Operating entertainment systems and small appliances at tailgates

and outdoor events.

Because the manual for a 1850 Coleman Powermate generator provides the exact rated wattage and surge capacities, it is your first resource for determining which devices you can safely run simultaneously. Overloading the generator is a common mistake that can be avoided by consulting this document.

---

## THE CRUCIAL ROLE OF THE MANUAL FOR A 1850 COLEMAN POWERMATE GENERATOR

---

Many owners overlook the importance of the owner's manual, relying instead on general knowledge. However, the **manual for a 1850 Coleman Powermate generator** is not generic. It contains specific information that is

critical for safe and efficient operation. Without it, you risk improper maintenance, voiding warranties (if any remain), and creating dangerous operating conditions.

# Safety Information Unique to Your Model

Every generator presents specific hazards, including carbon monoxide poisoning, electrical shock, and fire risks from fuel and hot engine parts. The manual for a 1850 Coleman Powermate

generator will outline:

- Proper grounding procedures for your unit's electrical system.
- Clearances required from windows, doors, and vents to prevent CO buildup.
- Fuel storage and handling precautions specific to the generator's fuel system.
- Electrical load limits and wiring diagrams for the control panel.

# Performance Specifications

## and Capacities

Beyond basic wattage, the manual provides detailed technical data including:

- Engine displacement and oil capacity (typically around 15-20 ounces).
- Fuel tank capacity and estimated run time at 50% load.
- Voltage and amperage ratings for each outlet (typically 120V, 15A-20A).
- Recommended fuel types and octane ratings.
- Spark plug gap and type specifications.

## Maintenance Schedules Tailored to the Engine and Alternator

One of the most valuable sections in the **manual for a 1850 Coleman Powermate generator** is the maintenance schedule. It tells you exactly when to change oil, clean or replace the air filter, inspect the spark plug, and service the fuel system. Following this schedule is the single

most important factor in preventing unexpected breakdowns.

---

### **KEY SPECIFICATIONS YOU WILL FIND IN THE MANUAL FOR A 1850 COLEMAN POWERMATE GENERATOR**

---

While specifications can vary slightly between production years, most Coleman Powermate 1850 models share a core set of characteristics. Knowing these specs helps you source correct parts and operate the generator safely.

| <b>Specification</b> | <b>Typical Value</b>                   |
|----------------------|----------------------------------------|
| Surge Wattage        | 1850 watts                             |
| Continuous Wattage   | 1500 - 1650 watts                      |
| Engine               | Briggs & Stratton<br>875 or 900 series |

|                      |                               |
|----------------------|-------------------------------|
| Fuel Tank Capacity   | 3.5 - 5 gallons               |
| Run Time at 50% Load | 8 - 12 hours                  |
| Oil Capacity         | 15 - 20 oz (SAE 30 or 10W-30) |
| Spark Plug Gap       | 0.030 inches (0.76 mm)        |
| Outlets              | 2x 120V AC, 1x 12V DC         |
| Weight               | Approximately 90-110 lbs      |

Always verify these figures against your specific manual for a 1850 Coleman Powermate generator, as there may be differences depending on the exact model number printed on your unit's data plate.

---

## FOR A 1850 COLEMAN POWERMATE GENERATOR

---

If you do not have the original paper manual, do not worry. There are several reliable ways to obtain a copy.

# Online Resources and Manufacturer Archives

Coleman Powermate has been through several ownership changes over the decades, but manuals for older models

## WHERE TO FIND THE MANUAL

or find them online. Start by visiting the current Powermate website (powermate.com) and navigating to their support or manual lookup section. You will likely need the model number and serial number from the generator's identification sticker. If the official site does not have it, try third-party manual repositories such as ManualsLib, ManualsOnline, or GeneratorManual.com. A simple search for "manual for a 1850 Coleman Powermate generator" will often bring up a downloadable PDF.

## Online Forums

## and Community Support

Vintage generator enthusiast communities are a treasure trove of information. Sites like SmokStak, ArboristSite, and various Facebook groups dedicated to Coleman and Powermate equipment have members who have scanned and shared manuals. Posting a request for the manual for a 1850 Coleman Powermate generator in these communities can yield a quick response from someone who owns the same machine.

## Used Market and Vintage Equipment Dealers

Occasionally, sellers on eBay, Craigslist, or at flea markets will have original paper manuals available for purchase. If you are buying a used generator that is missing its manual, ask the seller politely if they have it or know where to find one. Some small engine repair shops also maintain a library of manuals for older equipment and may allow you to make a copy.

---

## OPERATING YOUR GENERATOR SAFELY USING THE MANUAL

---

Safety is paramount when operating any generator. The **manual for a 1850 Coleman Powermate generator** contains specific safety instructions that you must follow. Here is a summary of the most critical points:

## Proper Starting Procedure

1. Place the generator outdoors in a dry, well-ventilated area away from windows, doors, and vents.
2. Check the oil level and fuel level. Use the recommended oil viscosity from the manual.

3. Turn the fuel valve to the “ON” position.
4. Set the choke to the “START” position (usually full choke when cold).
5. Pull the recoil starter cord gently until resistance is felt, then pull sharply.
6. Once the engine starts, gradually move the choke to the “RUN” position.
7. Allow the engine to warm up for a few minutes before connecting any loads.

## Electrical Load

# Management

Your manual for a 1850 Coleman Powermate generator will list the maximum current for each outlet. Never exceed these ratings. Use a heavy-duty extension cord rated for outdoor use and ensure it is fully unwound to prevent overheating. Add loads in sequence, starting with the largest motor-driven appliance (which requires the most starting surge).

2. Let the engine run at no load for a minute or two to cool down.
3. Turn the fuel valve to the “OFF” position and allow the carburetor to run dry.
4. Turn the engine switch to “OFF” (if equipped).
5. Store the generator in a clean, dry area. If storing for more than 30 days, add fuel stabilizer to the tank following the manual’s instructions.

# Shutdown and Storage

1. Disconnect all loads before turning off the generator.

---

## MAINTENANCE AND SERVICE INTERVALS FROM THE MANUAL

---

Regular maintenance is the key to long generator life. The **manual for a 1850 Coleman Powermate generator** provides a schedule that, if followed, will keep your machine starting and running

reliably for decades.

## Oil Changes

Most manuals recommend changing the engine oil after the first 5-8 hours of operation (break-in period) and then every 50 hours or every season, whichever comes first. Use high-quality SAE 30 or 10W-30 detergent oil. Never overfill; check the dipstick level carefully.

## Air Filter Maintenance

Check the foam air filter every 25 hours

of operation in normal conditions, and more frequently in dusty environments. Clean it with warm, soapy water, rinse thoroughly, and allow it to air dry completely. Lightly oil the foam with engine oil and squeeze out excess before reinstalling. Replace the paper air filter element if your model has one. The manual will specify the correct filter part number.

## Spark Plug Service

Remove and inspect the spark plug every 100 hours. Clean it with a wire brush and check the gap with a feeler gauge